

Digital Villa VTO (VTO6 Series)

User's Manual

V2.0.0

1 Product Overview

1.1 List of Models

This manual applies to multiple product models; please carefully confirm your model and its features.

Model	Chassis Material	Color	Unlock via IC card	Button Type	Lock Control Module
VTO6000A	Metal	Metal grey	N/A	Mechanical key	External
VTO6110B	Fireproof ABS	Black	Support	Touch button	External
VTO6110BW	Fireproof ABS	White	Support	Touch button	External
VTO6210B	Fireproof ABS	Black	Support	Touch button	Built-in
VTO6100C	Fireproof ABS	White	Support	Mechanical key	Built-in
VTO6000C	Fireproof ABS	White	Not support	Mechanical key	Built-in
VTO6000CM	Metal	Metal grey	Not support	Mechanical key	Built-in

1.2 VTO6000A

1.2.1 Front Panel




Figure 1- 1 VTO6000A

No.	Port Name	Note
1	Nameplate	You can fix company nameplate here.
2	Compensation Light	Light compensation will automatically turn on during monitoring, calling, or connecting status if there is no enough light in environment.
3	Camera	It monitors corresponding door region.
4	Call Button	Call center or VTH.
5	Speaker	Audio output.
6	MIC	Audio input.

1.2.2 Rear Panel




Figure 1- 2 VTO6000A

No.	Component Name	Note
1	Power	Connect to 12V DC.
2	RS485 Port	May connect to access control extension module
3	Network Port	Plug in network cable (RJ45 port) .

1.3 VTO6110B/VTO6110BW/VTO6210B

1.3.1 Front Panel

VTO6110B, VTO6110BW and VTO6210B's front panel is as in Figure 1- 3.




Figure 1- 3 VTO6110B/VTO6110BW/VTO6210B

No.	Component Name	Note
1	Compensation Light	Light compensation will automatically turn on during monitoring, calling, or connecting status if there is no enough light in environment.
2	Camera	It monitors corresponding door region.
3	Card Swiping Area	Authorize IC card and unlock by swiping IC card (must connect to access control extension module).
4	Call Button	Lightly touch button area, to call center or VTH. Blue NO: VTO is under standby status.

1.3.2 Rear Panel

VTO6110B and VTO6110BW's rear panel is as in Figure 1- 4 VTO6110B and VTO6110BW.




Figure 1- 4 VTO6110B and VTO6110BW

No.	Component Name	Note
1	Vandal Proof Switch	It will generate alarm sound and report to the center once VTO is forced to leave the wall.
2	Network Port	Plug in network cable (RJ45 port) .
3	Power	Connect to 12V DC.
4	RS485 Port	May connect to access control extension module.
5	Speaker	Audio output

VTO6210B's rear panel is as in Figure 1- 5 VTO6210B.




Figure 1- 5 VTO6210B

No.	Component Name	Note
1	Vandal Proof Switch	It will generate alarm sound and report to the center once VTO is forced to leave the wall.
2	Network Port	Plug in network cable (RJ45 port) .
3	Power	Connect to 12V DC.
4	RS485 Port	May connect to door lock, door sensor and unlock button. It reserves port for other device.
5	Speaker	Audio output

1.4 VTO6000C/VTO6000CM/VTO6100C

1.4.1 Front Panel

VTO6000C and VTO6000CM's front panel is as in Figure 1- 6 and VTO6100C's front panel is as in Figure 1- 7.




Figure 1- 6 VTO6000C and VTO6000CM




Figure 1- 7 VTO6100C

No.	Component Name	Note
1	Compensation Light	Light compensation will automatically turn on during monitoring, calling, or connecting status if there is no enough light in environment.
2	Camera	It monitors corresponding door region.

3	Card Swiping Area	<p>Authorize IC card and unlock by swiping IC card (must connect to access control extension module).</p> <p>Note: Only VTO6100C supports IC card unlocking function. Silk-screen in this area may vary for different product.</p>
4	Call Button	<p>Lightly touch button area, to call center or VTH.</p> <p>Blue NO: VTO is under standby status. Blue flashing: VTO is calling or in call status. Yellow: IC card unlocking or call is abnormal.</p>

1.4.2 Rear Panel




Figure 1- 8 VTO6000C/VTO6000CM/VTO6100C

No.	Port Name	Note
1	Network Port	Connect to network cable (RJ45 port) .
2	Power	Connect to 12V DC.
3	Debug Port	For installer use.
4	Green Port 1	Connect to lock.

5	Green Port 2	Connect to door sensor and unlock button.
----------	--------------	---

2 Introduction to Web

2.1 Login

Here takes VTO6210B as an example.

First, make sure both PC and the VTO are connected to the Internet and follow these steps to login Web management page.

Step 1. In Internet Explorer input the IP address of VTO, press Enter. You will see the login page as in Figure 2- 1.



Figure 2- 1

Step 2. Input username and password.

Step 3. Click on Login.

Note: The default IP address of VTO is 10.22.5.189 or 192.168.1.110. Default username password is admin/admin. After you login for the first time, please change the password for security purpose.

2.2 System Config

2.1.1 Local Config

2.2.1.1 Local Config

In Local Config interface, you can view VTO model, version info and etc.




Figure 2- 2

Parameter	Note
VTO Model	Display VTO model, such as villa VTO, unit VTO.
Video Format	Set video format that collected by the camera, including: WVGA and D1. WVGA resolution is 800x480; D1 resolution is 704x576.
Reboot Date	On the set date, device will automatically reboot.
Volume Config	Adjust device volume, range 0~100.
Frame Rate	NTSC: 30 fps, PAL: 25 fps.
Version Info	Display device version info.
Restore Backup	Mainly used to restore card no. and VTH info, refer to Ch 3.7.
Default	Only restore current Local Config page to default settings.
Default All	Device restores all parameters to default settings. Every 30 minutes, VTO automatically saves card no. and VTH information in the system.

2.2.1.2 A&C Manager




Figure 2- 3

Parameter	Note
Unlock Responding Interval	The interval between current unlock and next one, unit is second.
Unlock Period	Period door remains unlocked, unit is second.
FTP IP, FTP port, FTP user, FTP password	FTP server is used to store picture taken when card is swiped at VTO. User can login FTO to get these pictures.
Issue Card	Activate IC card of the VTO so user can swipe the IC card to unlock. Note: Please refer to Digital Villa VTO (VTO6 Series) Installation Guide V 2.0.0

2.2.1.3 System Time

Here you can set date format, time format, and input system date and time. You can also click on Sync PC to synchronize system time with PC time.

2.2.2 LAN Config

Here you can register VTO to center and set how to call center. Please refer to Ch 3.1.1.

2.2.3 Indoor Station Manager

In Indoor Station Manager interface, you can add VTH (digital indoor station), view VTH info and delete VTH.




Figure 2- 4

Add VTH

In Indoor Station Manager interface, click on Add. The system pops up a window as in Figure 2- 5.

FamilyName

FirstName

VTH Short No.

IP Address

OK Cancel

Figure 2- 5


Fill in VTH info as user's name, VTH short no. and IP address.

Note:

VTH short no. consists of four digits, the first two digits can be within 01~99, the last two digits can be within 01~16.

2.2.4 Network Config

Here you can set VTO IP address, Subnet Mask and Default Gateway.
After you have modified IP address, Web page will reboot and go to the new IP address web page.



The screenshot shows the 'Network Config' page of the 'IP VDP Door Station Web Server V1.0'. On the left is a navigation menu with 'System Config' expanded to show 'Network Config' selected. The main area contains four input fields: 'IP Address' (10 . 15 . 5 . 242), 'Subnet Mask' (255 . 255 . 0 . 0), 'Default Gateway' (10 . 15 . 0 . 1), and 'MAC Address' (90 - 02 - a9 - 80 - 41 - 98). Below these fields are three buttons: 'Default', 'Refresh', and 'OK'.

Figure 2- 6

2.2.5 Change Password

Here you can change login password of VTO webpage.

2.3 Info Search

2.3.1 Call History

Here you can view call history of VTO in Call History interface. It can save up to 1124 items. .

IP VDP Door Station Web Server V1.0

System Config
Info Search
Call History
Status Statistics
Logout

VTO Call History

Index	Call Type	Room No.	Begin Time	Talk Time(m)	End State
1	Outgoing	101	0	00:00	Missed
2	Outgoing	101	0	00:00	Missed
3	Outgoing	101	0	00:00	Missed
4	Outgoing	101	0	00:00	Missed
5	Outgoing	101	0	00:00	Missed
6	Outgoing	101	0	00:00	Missed
7	Outgoing	101	0	00:00	Missed
8	Outgoing	101	0	00:00	Missed
9	Outgoing	101	0	00:00	Missed
10	Outgoing	101	0	00:00	Missed
11	Outgoing	101	0	00:00	Missed

1/94 Go to

Figure 2- 7

2.4 Status Statistics

2.4.1 VTH Status

Here you can view connection status of VTH.

- Status

Offline: VTO and VTH are not connected, you cannot call, monitor, talk or etc.

Online: VTO and VTH are connected, you can call, monitor, talk and etc.

- MON

- Unmon: VTH is not monitoring.

- Onmom: VTH is monitoring.

IP VDP Door Station Web Server V1.0

System Config
Info Search
Status Statistics
VTH Status
Logout

VTH Status

VTH	Status	MON	IP:PORT	REG_TIME	OFFTIME
101	Offline	Unmon	172.5.2.133:0	0	0
196	Offline	Unmon	172.5.2.186:0	0	0
197	Offline	Unmon	172.5.2.143:0	0	0
198	Offline	Unmon	172.5.2.186:0	0	0
199	Offline	Unmon	172.5.2.186:0	0	0

1/1 Go to

Figure 2- 8

2.5 Logout

Here you can reboot device or logout.

Click on logout to log out the system and it returns to login page.

3 Basic Function Introduction

3.1 Call Function

3.1.1 Call Manager Center

Check Register to the MGT Center, you can touch the button to call manager center. Now VTO can only call MGT Center. Manager center's time can be set on management platform or villa VTO's web-end. Once manager center picks up the call, you can perform a visual bidirectional talk with the manager center. You can touch the button on VTO to end call at any time.

Step 1. According to VTO configured for the center, fill in building no, building unit no. and VTO no.

Step 2. In LAN Config, check register to the MGT center, as in Figure 3- 1.

Step 3. Fill in MGT center IP address and MGT port no.

Step 4. Set call VTS time. Within this period, VTO can only call the center.

Step 5. Check Call VTS or not.

Step 6. Confirm all config, and click on OK. Enter Logout→ Reboot Devices, to manually reboot the device.

The screenshot displays the 'LAN Config' interface of the 'IP VDP Door Station Web Server V1.0'. The left sidebar contains a navigation menu with 'LAN Config' selected. The main content area includes the following configuration options:

- Group Call
- Building No.: 7
- Building Unit No.: 1
- VTO No.: 6901
- Register to the MGT Centre
- MGT Centre IP Address: 10 . 33 . 5 . 227
- MGT Port No.: 12801
- Call vts time: 00 : 00 To 00 : 00 Call vts or not
- From VTO IP Address: [VTO IP Setup]

A red warning message is displayed: "Warning: The device needs reboot after modifying the config above." At the bottom, there are three buttons: "Default", "Refresh", and "OK".

Figure 3- 1

3.1.2 Call User

Press Call button under standby status, and the VTO will call user. User may monitor VTO from VTH.

- On VTH, press Unlock button to unlock door.
- When VTH picks up, you can start talk with the VTH.
- If no one answers the call, then the call will end automatically and device returns to standby status.

3.1.3 Group Call

Group call is mainly used for one VTO. Press Call button on VTO to call multiple VTH at the same time.

VTH consists of master VTH and extension VTHs. A system can only have a max of 1 master VTH and 5 extension VTHs. Please refer to Digital Villa VTO (VTO6 Series) Installation Guide V 1.0.0.

3.2 Monitor

Both VTS and VTH are able to monitor this VTO by enabling the camera to capture local circumstance.

3.3 Unlock Function

Unlock by Center

When center is called, calling or monitoring, center can remotely unlock door. VTO will return to standby interface after call ends or countdown stops.

Unlock under Calling Status

When VTH is called, calling or monitoring, VTH can remotely unlock door. VTO will return to standby interface after call ends or countdown stops.

Unlock by IC Card

At the card swiping area on VTO, swipe authorized IC card. You can unlock door when you pass identification.

3.4 Issue Card

Place IC card at the card swiping area to authorize it. User can swipe IC card to unlock door.

Note:

Some products do not support IC card, please refer to Ch 1.1.

The VTO supports two methods to issue card: platform and WEB. Please refer to Digital Villa VTO (VTO6 Series) Installation Guide V 1.0.0.

3.5 Compensation of Light

In dark environment or at night, the VTO adopts auto photoreception technology which achieves light compensation in connecting status.

3.6 Vandal Proof

There is one channel of vandal proof which will generate alarm sound and report to the manager center once VTO is forced to leave the wall.

3.7 Restore Backup

Restore Card Info

If you encounter abnormality with card info or accidentally restore default settings, you can restore card info with this function.

Restore VTH Info

If VTH info is mistakenly changed, you can restore VTH info with this function.

Note: Every half hour, VTO automatically saves card and VTH info in the system. If you want to restore card and/or VTH info, you must restore within half hour after your last operation that change these info.

4. FAQ

1. Q: I pressed the touch button, and the indicator turned on, but the VTO did not start a call?
A: Please check your operation process.
2. Q: How to end a call when I am calling?
A: Please press button on VTO and there will be sound from the device.
3. Q: The device could not boot up and there was no sound or light.
A: Please check if power supply is well plugged.
4. Q: My call did not go through.
A: It is network connection error; please check the cables of the device and its extension.
5. Q: VTO did not respond after I swiped IC card.
A: Please check if your card is authorized.
6. Q: It says the card is invalid.
A: Please contact the administrator for confirmation.
7. Q: I heard a beep sound when I swiped IC card, but the door did is still locked.
A: Please check if your card is authorized.
8. Q: I have other problems not included above.
A: Please contact technical staffs for assistance.