




Product code: SBI-2020



SCAN QR CODE FOR DETAILED INSTRUCTIONS



This manual applies to Zigbee Door/Window sensor.
This manual is for reference only.
We advise for installation to be performed by professionals. Please see our website for most detailed instructions. www.sensbi.com

Introduction

This manual provides instructions for setting up and using the Zigbee Door/Window Sensor. The sensor detects the opening and closing of doors and windows, allowing integration with other devices for smart scenarios.

Specification


Name	Zigbee Door/Window Sensor
Battery Type	CR2032
Working Temperature	-10°C~55°C
Working Humidity	10%-90%RH (No Condensation)
Wireless Connection	Zigbee 3.0

Note: Ensure the door/window magnet is aligned with the sensor's alignment mark.

Add device to your app

1. Download the Sensbi app, register if necessary, and login to your account.

Sensbi app is available for both iOS and Android OS. Search the name 'SENSBI' in App Store or Google Play Store.



- 2. Important note before getting started:**
All Zigbee devices require an operating Zigbee gateway like Sensbi HUB1.

3. Connect your smartphone to Wi-Fi. Ensure the product is within the effective range of the Zigbee network provided by the zigbee gateway. Make sure the zigbee gateway is added to your network.
4. Power on the device and ensure your smartphone is connected to the network and has successfully added the zigbee gateway.
5. Open the Sensi app, go to the your zigbee gateway page, click "Add Device," and select "Door/Window Sensor" on the "Select Device Type" page.
6. Use the reset needle to press and hold the reset button for more than 5 seconds until the network indicator flashes. Follow the app's instructions to add the device.
7. Once added, the device will appear in the "My Home" list.

Packing List

- Door/Window Sensor x 1
- Adhesive backing x 1
- Battery x 1
- Reset Needle x 1
- Product User Manual x 1

