

Professional meeting microphone instruction manual

This product is specially designed and various kind of meeting, lecture, broadcasting and recording occasion etc. The unique prelude music function and light ring show, with the import electric capacity sound head, which demonstrate its functions and charismatic.

Capsule type : Condenser

Polar Pattern :Cardioided

Frequency Response : 60 – 18000Hz

Sensitivity : - 42 +/- 2dB

Power Supply : AC 12V

Operation Instruction :

1. Fill in the batter with correctly polar. Insert the audio the audio cord into the terminal.
2. Turn the volume of amplifier to “ 0 “ position, and turn on the amplifier and the condenser have the best effect.
3. On the back of the bas has a prelude music volume control, which can adjust the volume or turn off the music.