Insite Gold Setup Guide

March. 12th 2017 Created by: Moshe Blitz

Preface

This document will take you step by step through the setup process of creating new PMH account with Insite Gold application and help with setting up Babyware application.

Known Limitation

- 1. No support for HD77 camera
- 2. No support for site where IP150 or PCS password was changed from its default
- 3. Partial support for replacing IP150 or PCS communication modules
- 4. No support for site ID contain spaces at the end
- 5. No support for site ID using special characters such as: &
- 6. No support for adding camera after new site with no camera was created. Support is expected to be available on Android application version 1.5 and up
- 7. No support for some models of cellular routers with HD78 camera setup, due to lack of real UPNP support on router
- 8. Support only for Panel on-board PGMs with EVOHD

Prerequisite FW upgrade

- 1. Upgrade Panel FW version to the latest version posted on Paradox web site
- 2. Update PCS communication module FW version to the latest version posted on Paradox web site
- 3. Upgrade IP150 to FW version 4.0.4 and up.

Notes:

a. iPardaox will no longer be supported once upgraded.

b. FW downgrade is not supported

- c. Once PMH account is set
 - a. Use Babyware version 4.0.8 and up to connect. Any previous versions can't be use.
 - b. Use Infield version 4.0.7 and up. Any previous versions can't be use. Note that using Infield requires setting port forwarding in the router

www.paradox.com

IP150 Setup

Connect IP150 via browser and verify that IP Firmware version is 4.00.04 and that Panel Firmware version is the latest posted on Paradox website. Upgrade Panel firmware version as necessary

Welcome, System Master		Panel
Change password Logout	Туре	SP6000
Main menu	Firmware version	(6.11)
System Status	Serial number	29 0F 2C 6B
System Information		
IP150 Configuration		IP module
Receiver Configuration		
Email Configuration	Firmware version	4.00.04
Account Configuration	Hardware	020
I/O Configuration	ECO	N009
Event Log	Serial boot	N/A
Legend	IP boot	2.12
Area	Serial number	71 04 CB D0

Enable Paradox MY Home service and set polling time to 1 minutes then save

	ParadoxMyHome.com
Enable service Polling time	YesNominute(s)
	Save



Install Insite Gold

Download and install Insite Gold from Google Play or Apple App Store

PMH account setup For Site without HD78 Cameras

Note: If you do have HD78 camera, please continue with the section called 'PMH account setup For Site with Cameras' in this document.

- 1. Launch Insite Gold
- 2. Click on the menu icon



3. Click on New Installation

New Installation	
Languages	
About	

4. Click on Create



5. Select Site without Cameras

Site Type		
Site with Camera For mixed installations, start with Wi-Fi. Make sure the tamper is open.		
WI-FI Enable device hotspot ID and password: Paradox1		
ETHERNET Camera and devices connect to the same router/network.		
Site without Camera		
SELECT IP150 / PCS		
CANCEL		

6. Enter Control Panel Serial number and click OK

Add new Comn	nunication module
Enter Control Panel serial number	<u> </u>
	OK CANCEL

www.paradox.com

7. Check the IP150 module connected to the Panel and click Next

Modules List	
Paradox Security Systems Zone #	
Type IP150 Address 37 142 123 244:10000	
S/N 710472d1	
Paradox Security Systems	
Zone #	
Type IP150	\smile
Address 37.142.123.244:80	
S/N 71047aac	



- 8. If this is the first time you create site and you don't have your email already registered with Insite Gold, press 'Create PMH user', fill in all necessary information and press 'Create' A confirmation email will be sent to the email address you have just registered
- 9. Open mail inbox, locate the email received and verify the new account



P 🔺 R 🔺 D O X*

 Enter Site Name, Site ID and a valid email address and click Create New Site. Make sure to have access to the email entered as you will need to activate ParadoxMyHome token when prompt as part of the setup process. Site name is the one to appear in site list when using Insite Gold application. Site ID is the one registered on PMH server.

Notes: 1.DO NOT PRESS OK in the message appear until after email is verified. 2.DO NOT quite the application and remove it from background

Insite Gold	
Create New Site	
Site Name (Optional)	
Gadi	
Site ID (In PMH)	
Gadi	
PMH Email 🤡	
moshe.blitz@gmail.com	
Create PMH User	



Note: On iPhone, you may need to press 'Create New Site' one again to get to the next screen

11. Select plan and enter payment details



12. Check email and approve token activation then press OK Note: Do NOT close the application now, as it will not create new site. You can move the application to work in background until you validate the token, then press OK in the application



13. Enter Master PIN code of the Panel. PIN code is the one assigned to User001

	Connect	
Gadi		
	User Code	
	Connect	

www.paradox.com

P 🔺 R 🔺 D O X**

14. You are set and ready to go







7. Click on Create



P 🔺 R 🔺 D O X*

9. Select WiFi

Site Type
Site with Camera For mixed installations, start with Wi-Fi. Make sure the tamper is open.
WI-FI Enable device hotspot ID and password: Paradox1
ETHERNET Camera and devices connect to the same router/network.
Site without Camera SELECT IP150 / PCS
CANCEL

10. Application will locate and display all cameras that are connected to "Paradox1"

- 11. Locate the camera that you wish to install, press 'Configure' enter camera name in 'Camera Label' then press 'Config', and set zone number. Make sure the zone is free. Configure Sensitivity and Security Settings and press 'Save' Note:
 - 1. Camera should show an image. If black image is seen, power cycle camera or dismount front cover and re-attached it then try again.
 - 2. By default, zone is set to 'Follow' type. If you wish to make change, you can do so through Babyware or Keypad
 - 3. Zone setting on EVOHD panel is not supported and this have to be done using Babyware
 - 4. In some cases, multiple press on 'Locate Cameras' are needed to see the new camera



12. Locate the camera once again and press 'Configure', select the router Wi-Fi network you wish the camera to connect and type the password then press 'Apply'

| 1 🖳 🗣 🗚 🛎 🙋 🛛 💿 🖹 🗎 16:15 🛔 🖳 🗣 🗛 🛎 🙋 🛛 🔍 🗮 16:16



13. Repeat steps above for any additional camera you wish to associate with Insite Gold site

- 14. Switch phone from Hot Spot back to the same Wi-Fi network the camera is connected to
- 15. In the locate screen, press 'Next' and 'Next' again then 'Locate'



16. Press all the checkboxes associated with the cameras you wish to add to Insite Gold site and press 'Next'

Note:

- 1. If camera is not listed, press "Locate Cameras"
- 2. Each time a check the box is pressed, the Application verify with Paradox server that camera is accessible from the internet and that it is not registered with another site. Once these conditions are met, Camera checkbox is checked

17. Close camera's Tamper

P 🔺 R 🔺 D O X*

18. If this is the first time you create site and you don't have your email already registered with Insite Gold, press 'Create PMH user', fill in all necessary information and press 'Create' An email will be sent to the email address you have just registered.

19. Open mail inbox, locate the email received and verify the new account

Activation for m_blitz@hotmail.com - F

Thank you for creating a new account in ParadoxMyHe

Ref: 586e58dafde6474102d23298

Account Details

Email Address: m_blitz@hotmail.com First Name: Last Name: Address:

Please click to activate your account.

www.paradox.com

P 🔺 R 🔺 D O X*

20. Enter Site Name, Site ID and a valid email address and click Create New Site. Make sure to have access to the email entered as you will need to activate ParadoxMyHome token when prompt as part of the setup process. Site name is the one to appear in site list when using Insite Gold application. Site ID is the one registered on PMH server.

Notes: 1.DO NOT PRESS OK in the message appear until after email is verified. 2.DO NOT quite the application and remove it from background

Insite Gold	
Create New Site	
Site Name (Optional)	
Gadi	
Site ID (In PMH)	
Gadi	
PMH Email 🤡	
moshe.blitz@gmail.com	
Create PMH User	

Create New Site

17

21. Select plan and enter payment details

22. Check email and approve token activation then press OK Note: Do NOT close the application now, as it will not create new site. You can move the application to work in background until you validate the token, then press OK in the application

- 23. Application screen shows the different Sites and their status. Note that this may take few minutes to complete
- 24. Tap the site ID you wish to work with
- 25. Enter user name and code as configured in the panel (default UserName: master; Default Password: 1234)

26. You are set and ready to go

No Push Events

Babyware Setting

Set Babyware 4.x.x to use IP/DNS connection, enter Site ID and Site email of the corresponded Insite Gold account, enter the IP module password and click OK. Alternate, you may connect using Panel S/N

Settings	2	3
Connection Advanced Encryption Alarm System Label		
 Automatically upload panel changes to Babyware upon connection Programming changes New events Panel status (RAM) 		
[P/Panel S/N (should be used if no site is created on the system)	Serial	
Panel S/N	COM Port 🚽	
IP Module Password	Baud Rate Autodetect v	
IP/DNS (should be used if a site is created on the system)	Modem See Instruction	
Site ID	COM Port 🗸	
Email Address	Modem Type 📃 👻	
IP Module Password	* Modem init. string for Control Panel supporting 1200bps	
	Panel Phone # Telephone number	
GPRS/Public Network IP Address 192.168.0.1	Modem Response	
IP Port 10000	Advanced Test Windows Modern Options	
GPRS Module Password	Answering Machine Override	
Own Public IP Address 192.168.0.1 Call Back Port 15000	Ring Cycle Duration 0.0 🔄 Get Ring Cycle Duration	
GPRS/Static	GPRS/Private Network	
IP Address 192.168.0.1	Call Back Port 15000	
IP Port 10000	GPRS Module Password	
GPRS Module Password	SMS Initiation String Refresh	
X Cancel	✓ ОК	